

## DMX Values

| <b>STD.P</b> | <b>Channel</b> | <b>Function</b> | <b>Value</b> | <b>Percent/Setting</b> |
|--------------|----------------|-----------------|--------------|------------------------|
|              | 1              | Dimmer          | 000 ó 255    | 0–100%                 |
|              | 2              | Dimmer Fine     | 000 ó 255    | 0–100%                 |
|              | 3              | Strobe          | 000 ó 009    | No function            |
|              |                |                 | 010 ó 099    | Strobe (slow to fast)  |
|              |                |                 | 100 ó 109    | No function            |
|              |                |                 | 110 ó 179    | Lighting effect        |
|              |                |                 | 180 ó 189    | No function            |
|              |                |                 | 190 ó 255    | Random strobe          |
| <b>DOS</b>   | <b>Channel</b> | <b>Function</b> | <b>Value</b> | <b>Percent/Setting</b> |
|              | 1              | Dimmer          | 000 ó 255    | 0–100%                 |
|              | 2              | Dimmer Fine     | 000 ó 255    | 0–100%                 |
| <b>UNO</b>   | <b>Channel</b> | <b>Function</b> | <b>Value</b> | <b>Percent/Setting</b> |
|              | 1              | Dimmer          | 000 ó 255    | 0–100%                 |