

DMX Values

1CH	Channel	Function	Value	Percent/Setting
	1	Power Output On/Off	000 ∘ 152	No function
			153 ∘ 255	Turn on
			255 ∘ 103	No function
			102 ∘ 000	Turn off

4CH	Channel	Function	Value	Percent/Setting
	1	Power Output 1 On/Off	000 ∘ 152	No function
			153 ∘ 255	Turn on #1
			255 ∘ 103	No function
			102 ∘ 000	Turn off #1
	2	Power Output 2 On/Off	000 ∘ 152	No function
			153 ∘ 255	Turn on #2
			255 ∘ 103	No function
			102 ∘ 000	Turn off #2
	3	Power Output 3 On/Off	000 ∘ 152	No function
			153 ∘ 255	Turn on #3
			255 ∘ 103	No function
			102 ∘ 000	Turn off #3
	4	Power Output 4 On/Off	000 ∘ 152	No function
			153 ∘ 255	Turn on #4
			255 ∘ 103	No function
			102 ∘ 000	Turn off #4