

QUICK REFERENCE GUIDE



onAir Flex Drive 2

DMX Values

10CH–RGBW+Dx2

Address All

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇔ 255	0–100%
2	Green 1	000 ⇔ 255	0–100%
3	Blue 1	000 ⇔ 255	0–100%
4	White 1	000 ⇔ 255	0–100%
5	Dimmer 1	000 ⇔ 255	0–100%
6	Red 2	000 ⇔ 255	0–100%
7	Green 2	000 ⇔ 255	0–100%
8	Blue 2	000 ⇔ 255	0–100%
9	White 2	000 ⇔ 255	0–100%
10	Dimmer 2	000 ⇔ 255	0–100%

Address Sub1 or Sub2

Channel	Function	Value	Percent/Setting
1	Red 1 or 2	000 ⇔ 255	0–100%
2	Green 1 or 2	000 ⇔ 255	0–100%
3	Blue 1 or 2	000 ⇔ 255	0–100%
4	White 1 or 2	000 ⇔ 255	0–100%
5	Dimmer 1 or 2	000 ⇔ 255	0–100%

8CH–RGBWx2

Address All

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇔ 255	0–100%
2	Green 1	000 ⇔ 255	0–100%
3	Blue 1	000 ⇔ 255	0–100%
4	White 1	000 ⇔ 255	0–100%
5	Red 2	000 ⇔ 255	0–100%
6	Green 2	000 ⇔ 255	0–100%
7	Blue 2	000 ⇔ 255	0–100%
8	White 2	000 ⇔ 255	0–100%

Address Sub1 or Sub2

Channel	Function	Value	Percent/Setting
1	Red 1 or 2	000 ⇔ 255	0–100%
2	Green 1 or 2	000 ⇔ 255	0–100%
3	Blue 1 or 2	000 ⇔ 255	0–100%
4	White 1 or 2	000 ⇔ 255	0–100%